

Exhaust Kit suit Toyota HDJ100 3.5" Dump & 3" exhaust

Remove original pipes. Retain original mounts and rubbers.



Fit dump pipe to turbo, then pipe over front chassis. Leave bolts loose.



Fit muffler then 'over diff' pipe.



Use original mounts and rubbers.



Attach tail pipe and mount. Leave bolts loose.



Tighten all bolts and mounts. Some clearance be required to the upper control arm mount. Grind off to clear.